



Extended Climate Control



Entry point

User taps on the Climate Control button.




Step 1

User is presented with the Climate Control feature where he/she can set the desired temperature and activate heating/defrost modules, depending on the availability per car model and package.


All images shown are for illustration purpose only. Actual product may vary due to product enhancement.

Extended Climate Control



Step 2


User is informed of the security & legality of the feature. This overlay is always displayed before activating Climate Control unless the user ticks the “Don’t show me again” button.



Step 3

The request for activating Climate Control is initiated.

Extended Climate Control



Step 4

User is informed of the successful activation of the service.

Expected time for the climate to be initiated is **10-30 seconds**.




Step 5

As long the Climate Control is running, the user can check the following details:

- Timestamp when the data was last refreshed
- Set temperature
- Approximate time remaining
- Activated heating/defrost modules

When the Climate Control is running, the icon on the Car Section screen will be animated.

A young girl with brown hair, wearing a pink and grey jacket, is sitting in a car seat. She is holding a large, light-colored stuffed animal. A dog, possibly a husky or malamute, is sitting next to her on the same seat. The car's interior is visible, including the headrests and seat belts. The text "EXTENDED CLIMATE CONTROL" and "HOW TO SET SCHEDULE" is overlaid on the image in white, bold, sans-serif font.

EXTENDED CLIMATE CONTROL

HOW TO SET SCHEDULE

Extended Climate Control - Schedule



Entry point

The user can access the Schedule on Climate Control screen while Climate Control is running (right screen) and when it's off.



Schedule button when Climate Control is running.


All images shown are for illustration purpose only. Actual product may vary due to product enhancement.

Extended Climate Control - Schedule



Step 1


The user can view the list of schedules and summary of the schedule. Each schedule can be disabled from the list with the toggle button. Up to 10 schedules can be saved.



Step 2


There are two types of Schedules:
1. One-time schedule

Extended Climate Control - Schedule



Step 3

2. Repeat: user can select several days in the week.




Step 4

After the Schedule is saved, it will be visible on the Schedule List.


All images shown are for illustration purpose only. Actual product may vary due to product enhancement.

Extended Climate Control - Schedule



Editing a schedule

The user can also Edit the schedule by tapping on the Schedule.




Delete a schedule

Delete the schedule by swiping left (or while editing).


All images shown are for illustration purpose only. Actual product may vary due to product enhancement.

Extended Climate Control - Schedule



Pause a schedule

Pause the schedule (use the toggle button to pause the schedule).



Paused schedules will appear grey in the Schedule List.

All images shown are for illustration purpose only. Actual product may vary due to product enhancement.



Connected Services are continually improving, therefore visuals and app screens in this guide may slightly differ from those seen in your SUBARU Care app.